

Access Admin / Network Settings

1. From the main screen, tap all 4 corners of the screen (one after another, clockwise or counterclockwise)
 2. Password prompt will appear
 3. Enter:
 - pax9876@@ (alt: 123456)
 4. Open:
 - Settings
 5. Navigate to:
 - Network & Internet
-

OPTION 1: DHCP (For IP Reservation)

On Device

1. Go to:
 - WLAN or Ethernet
 2. Set:
 - IP Settings → DHCP
-

For Reservation (Router / DHCP Server)

1. Retrieve MAC Address from device network settings
 2. Configure DHCP Reservation on router/server:
 - Assign desired IP to MAC address
 3. Reboot or reconnect device if needed
-

OPTION 2: Static IP Configuration

Wi-Fi (WLAN)

1. Tap WLAN
2. Select SSID
3. Enter Wi-Fi password
4. Tap Advanced Options
5. Set:
 - IP Settings → Static
6. Enter:
 - IP Address
 - Gateway
 - Network Prefix Length
 - DNS 1
 - DNS 2
7. Tap Connect

Ethernet

1. Tap Ethernet
2. Select:
 - IP Mode / Ethernet IP Mode
3. Set to:
 - Static
4. Enter:
 - IP Address
 - Gateway
 - Network Prefix Length
 - DNS
5. Tap Connect / Save

